



MILLING AND CLEANING SET FOR TYRE VALVES

Manual

12155000



PICHLER
tools since 1978.

MILLING AND CLEANING SET FOR TYRE VALVES



Nr.	PART.-NR.	Description
	12155001	Mounted point stepped Ø11.6 mm / Ø17.0 mm
	12155004	Mounted point stepped Ø11.6 mm / Ø20.0 mm
	12155006	1/4" hexagonal bit extension 140 mm
	12155003	Holder "long" for mounted points
	12155002	Holder "short" for mounted point
	12155007	Face scraper for rim valve seat cleaning, with guide pin, stepped Ø11.5 mm / Ø17.0 mm
	85000910	Neodymium magnetic mat, extra strong, size 1, 305x50x7 mm / 5 magnets

ACCESSORIES

12155005	Grinding pin stepped Ø11.6 mm / Ø17.0 mm, 3 pcs.
12155010	Grinding pin stepped Ø11.6 mm / Ø20.0 mm, 3 pcs.

PREPARATION

The tire and the rim valve must be removed from the wheel rim before starting the cleaning work.



The application of the respective mounted points with holder may only take place clockwise!

CLEANING THE INTERNAL SEALING SEAT OF THE TYRE VALVES IN ALLOY RIMS

The internal sealing seat of the tyre valves in alloy rims is cleaned by a graduated grinding pin Ø11.6 mm / Ø20.0 mm **12155004**, which is screwed into the "long" holder **12155003** in a clockwise direction. In the case of wide rims, the "long" holder **12155003** can be additionally extended by a 140 mm bit extension **12155006**.



Recommended speed for mounted points: up to 10,000 RPM!

CLEANING THE EXTERNAL SEALING SEAT OF THE TYRE VALVES IN ALLOY RIMS

The external sealing seat of the tyre valves in alloy rims is cleaned in two steps. In the case of very heavy corrosion contamination (see Fig. 3), it is advisable to pre-clean the sealing seat in the first work step using a face scraper **12155007**.



The external sealing seat of the tyre valves in alloy rims can then be cleaned by a grinding pin, stepped Ø11.6 mm / Ø17.0 mm **12155001**, which is screwed into the holder "short" **12155002** in a clockwise direction.



VIDEO



pichler.tools



/pichlerwerkzeug



/pichlerwerkzeug



/pichlerwerkzeug

AUSTRIA

✉ at@pichler.tools
☎ +43 512 344 552

GERMANY

✉ de@pichler.tools
☎ +49 8821 686 9780

SWITZERLAND

✉ ch@pichler.tools
☎ +41 61 981 33 55

FRANCE

✉ fr@pichler.tools
☎ +33 3 89 551 596

UK & IRELAND

✉ uk@pichler.tools
☎ +44 1335 360 759

BELGIUM

✉ be@pichler.tools
☎ +32 495 400 810

ITALY

✉ it@pichler.tools
☎ +39 0472 970 042

