



CLEANING BRUSH SET

Ø 6 MM, Ø 8 MM, Ø 10 MM, Ø 13 MM AND Ø 16 MM
WITH BRUSH HOLDER AND FLEXIBLE BIT HOLDER

MANUAL

9139000 / 9139005

SAFETY NOTICE

To understand the functioning of the tools, is it necessary to read the manual first!

- > Read these instructions before assembling, during installation and throughout use and in the proper sequence
- > Always refer to the OEM manufacturer's instructions and service manuals for the latest data and to maintain the correct sequence
- > These work instructions and the recommended tools are meant to serve as aides only and are by no means a guarantee for certain results.
- > This tool kit is a special collection and it has been tested and used successfully on several occasions. It is of the utmost importance to maintain the correct procedure as per the instructions
- > The use of the tools should only be carried out by qualified personnel!



ATTENTION

Special caution



CORRECT



LIGHT BULB

Hint or recommendation



WRONG




SAFETY GOGGLES

Wearing safety goggles
necessary


TWISTED-WIRE BRUSH CLEANING SET 22 PCS.

Part. Nr.: 9139000



TWISTED-WIRE BRUSH CLEANING SET 12 PCS.

Part. Nr.: 9139005




Nr.	PART.-NR.	Description	9139000	9139005
1	9039034	Flexible Bit Holder ¼"	1	1
2	9039036	Holder for tube brushes	1	1
3	9139006-1	Twisted-Wire Brush Ø 6 mm	4	2
4	9139008-1	Twisted-Wire Brush Ø 8 mm	4	2
5	9139010-1	Twisted-Wire Brush Ø 10 mm	4	2
6	9139012-1	Twisted-Wire Brush Ø 13 mm	4	2
7	9139016-1	Twisted-Wire Brush Ø 16 mm	4	2

- 1 Select the appropriate tube brush depending on the application.



Always use a tube brush with the same or next larger diameter of the to be cleaned bore.

- 2 Insert the Tube Brush till the stop into the Brush Holder and fasten it with two spanners (13 & 14).



- 3 Clamp the Brush Holder, as required, directly or in combination with the Flexible Bit Holder in a power drill.

4



- 5 Clean the bore rotating only clockwise.




6



SAFETY GOOGLES

Wearing safety goggles necessary



bore for the ABS sensor



caliper sliding guide (slide pin bore)

RECOMMENDED ACCESSORIES

SET OF CLEANING BRUSHES

90490300



TUBE BRUSHES IN DIFFERENT DIAMETERS

9039032	Ø18 mm
9039031	Ø19 mm
9039029	Ø21 mm
9039028	Ø24 mm
9039027	Ø26 mm



UNIVERSAL INJECTOR SHAFT CLEANING KIT

9038011



FLEXIBLE LAMP „BAL“

40103000



VIDEOSCOPE EXCLUSIVE Ø4,9MM

9078050



VIDEOSCOPE MOUNT

9078054



NOTES

PICHLER Werkzeug GmbH

Pacherstraße 20
A-6020 Innsbruck
at@pichler.tools
+43 512 344 552

Zugspitzstraße 33
D-82467 Garmisch-Partenkirchen
de@pichler.tools
+49 8821 6869 780

PICHLER Werkzeug AG

Rünenbergerstrasse 31
CH-4460 Gelterkinden
ch@pichler.tools
+41 61 981 33 55

PICHLER Utensili S.r.l. Uni Personale

Via Città Nuova 27
I-39049 Vipiteno
it@pichler.tools
+39 472 970 042

PICHLER Outillage Sàrl

19a, rue de Reiningue
68310 Wittelsheim, France
fr@pichler.tools
+33 3 89 551 596

PICHLER TOOLS LTD

Ednaston Business Centre
Hollington Lane, Ednaston
Ashbourne · DE6 3AE
uk@pichler.tools
+44 1335 360 759

PICHLER Outillage BV

Industrieweg 45
8800 Roeselare
Belgium
be@pichler.tools
+32 495 400 810



pichler.tools



/pichlerwerkzeug



/pichlerwerkzeug



/pichlerwerkzeug



www.pichler.tools

 **PICHLER**
built to succeed.